

1. Plug in CORE transmitter

Connect the transmitter DC adapter to the electrical outlet and use one of the 3 available audio inputs to connect the music source

2. Insert GLOBE in the lighting rail

Rotate the safety lug to secure the loudspeaker on the lighting rail

3. Power ON GLOBE

then rotate the selector wheel (3 positions) to match with the electric phase of the lighting rail

Check whether the unit is really powered or not by watching the LED indicators.
If blue and green LEDs start blinking the unit is ready to pair

4. Pair the devices

Make a short press on the WiS PAIR key (using a clip e.g.), the WiS and RX LEDs will start to blink

When the CORE and GLOBE lights stop blinking, the devices are paired

5. Select the input and play the music!

WiSpeak grip

Use WiSpeak grip app for set up and control functions

