# VCM36-W Datasheet

# Introduction

The Yealink VCM36-W is an innovative wireless video conferencing microphone designed to accommodate various meeting room needs. With a built-in 3-microphone array, the VCM36-W has a 20ft (6m) and 360° voice pickup range. It features Yealink's high-quality echo cancellation technology and noise cancellation, effectively filtering out up to 90dB of ambient noise to provide a high-quality audio experience during full-duplex calls.

The VCM36-W's high-quality pickup technology provides a full range of audio coverage for all conference room sizes.

The VCM36-W is easy to use with a single pairing, with up to 12 hours of battery life in conference mode and 7 days of standby time. The VCM36-W WIFI microphone is equipped with a charging dock that allows you to charge the microphone wirelessly, and you can change its deployment position at any time while using it to suit your needs.







voice pickup range

HD Hi-Fi Wifi Microphone Dup

Yealink Full Duplex Technology



12 hours battery life of conference

WPA2, AES128 Encryption Technology



#### **Key Features and Benefits**

- HD Hi-Fi Wifi Microphone
- Yealink Full Duplex Technology
- Dual-band 2.4GHz/5GHz wireless networks
- 6m-360° voice pickup range
- 12 hours battery life of conference
- WPA2, AES128 Encryption Technology

#### **Specifications**

Specifications	Description
----------------	-------------

· · · · · · · · · · · · · · · · · · ·	
Microphone Features	<ul> <li>Optimal HD Audio</li> <li>Yealink Full Duplex Technology</li> <li>Yealink Acoustic Echo Canceling</li> <li>Yealink Noise Proof Technology</li> <li>6 m voice pickup range</li> <li>Muting the microphone with touchpad</li> <li>Can be used as an expansion microphone</li> <li>Built-in 2450 mAh battery</li> <li>Up to 12 hours of use time</li> <li>Up to 7 days standby time</li> <li>Frequency response: 100Hz to 8kHz</li> </ul>
Wi-Fi	<ul> <li>Standard: 802.11 b/g/n/ac</li> <li>Frequency: 2.4GHz/5GHz</li> <li>Security: WPA-PSK/WPA2-PSK</li> </ul>
Physical Features	<ul> <li>Dimension (W DH):</li> <li>Microphone: 100 x 16.5 mm</li> <li>Charge Cradle: 100 x 10.5 mm</li> <li>Operating humidity: 10% - 90%</li> <li>Storage temperature: 0°C - 40°C (+32°F - 104°F)</li> </ul>
Package Contents	<ul> <li>1x VCM36-W Video Conference Microphone</li> <li>1x Charger Cradle</li> <li>1x 1.2 m USB-C Cable</li> <li>1x USB Adapter (not included for Thailand market)</li> <li>Double-sided adhesive</li> <li>Quick Start Guide</li> </ul>
Package Features	<ul> <li>Qty/CTN: 20 PCS</li> <li>N.W/CTN: 8.068 kg</li> <li>G.W/CTN: 8.678 kg</li> <li>Giftbox size: 184 x 112 x 60 mm</li> <li>Carton Meas: 635 x *237 x 200 mm</li> </ul>

# **Device Compatibility**

- Teams Room Accessories Compatibility Lists
- Zoom Rooms Accessories Compatibility Lists

#### How to Use

VCM36-W has different features when used with different video conferencing endpoints. For more information, please refer to the corresponding documents.

#### **Teams Verison**:

- Connect the VCM36-W to MeetingBar: VCM36-W Wireless Microphone
- Connect the VCM36-W to MVC System: VCM36-W Wireless Microphone
- Connect the VCM36-W to MeetingBoard: VCM36-W Wireless Microphone

# Yealink

#### Zoom Version:

- Connect the VCM36-W to MeetingBar: VCM36-W Wireless Microphone
- Connect the VCM36-W to ZVC System: VCM36-W Wireless Microphone
- Connect the VCM36-W to MeetingBoard: VCM36-W Wireless Microphone

#### **RingCentral Version**:

• Connect the VCM36-W to MeetingBar: VCM36-W Wireless Microphone

# **LED Indicator**

#### Charging LED Indicator:

LED Indicator Status	Description
Solid red	Charging
Solid green	The VCM36-W is fully charged
Flash red slowly	Low battery(lower than 20%), and please charge
Flash red 3 times and then off	The battery is too low to power on
Solid green for 3 seconds and then off	Standby
Solid green for one second and then off	Power on
Off	If you tap the mute button and the Charge indicator LED on the VCM36-W is still off, it means the VCM36-W is powered off

#### Mute LED Indicator:

LED Indicator Status	Description
Solid red	The system is muted
Solid green	The system can pick voice
Slowly flashing yellow	The VCM36-W is searching for signal
Off	The system is in the idle state

### **Hardware Introduction**



# Charge



#### **Power On and Off**

1. Press and hold the **Mute** button for 5 seconds.

The charging LED indicator turns green and then turns off during startup.

2. Press and hold the **Mute** button for 15 seconds.

The charging LED indicator turns red and then turns off. If the device does not respond after pressing the **Mute** button, it is powered off.

#### **Mute/Unmute Microphone**

- 1. Press the **Mute** button on the VCM36-W to mute the microphone. If the muting LED indicator is solid red, the microphone is mute.
- 2. Press the **Mute** button again to unmute the microphone.